

AnaGate CAN USB



User Manual

Analytica GmbH

J. Gossens, Analytica GmbH

AnaGate CAN USB: User Manual

Analytica GmbH
by J. Gossens

This document was generated with DocBook at 2016-04-07 11:03:45.

PDF-Datei (dtsch.): *AnaGate-CAN-USB-1.4.pdf*

PDF-Datei (engl.): *AnaGate-CAN-USB-1.4-EN.pdf*

Publication date 04. März 2016

Copyright © 2007-2016 Analytica GmbH

Abstract

This manual describes the interfaces and modes of operation of a *AnaGate CAN USB*.

All rights reserved. All the information in this manual was compiled with the greatest of care. However, no warranty can be given for it.

No parts of this manual or the program are to be reproduced in any way (printing, photocopying, microfilm or any other process) without written authorisation. Any processing, duplication or distribution by means of any electronic system is also strictly prohibited.

You are also advised that all the names and brand names of the respective companies mentioned in this documentation are generally protected by brand, trademark or patent laws.

Analytica GmbH
Bannwaldallee 60
76185 Karlsruhe
Germany
Fon +49 (0) 721-43035-0
Fax +49 (0) 721-43035-20
<support@analytica-gmbh.de>



www.analytica-gmbh.de [<http://www.analytica-gmbh.de>]
www.anagate.de [<http://www.anagate.de>]

Revision History			
Revision 1.0	01.10.2010	JGo	Initial version
Revision 1.1	05.10.2011	ASc	New option <i>Boot with operational mode</i> on web configuration side <i>CAN settings</i> (FW 1.3.16).
Revision 1.2	14.08.2013	ASc	Description of advanced unit settings on web configuration page <i>Advanced settings</i> (FW 1.3.19) and the informational <i>Status</i> page.
Revision 1.3	01.04.2014	ASc	Support of CANopen Conformance Test Tool of the CiA.
Revision 1.4	04.04.2016	JGo	Installation description for windows 10 added.

Table of Contents

Introduction	vii
1. Description	1
1.1. Features	1
1.2. Specification	1
1.3. Scope of delivery	2
1.4. Interfaces and plugs	2
2. Configuration	4
2.1. Initial installation	4
2.2. Network settings	17
2.3. CAN settings	18
2.4. Advanced settings	20
2.5. Device status	20
2.6. Functional extensions based on Lua	22
2.7. Factory reset	24
2.8. Firmware update	25
3. Fields of application	28
3.1. Gateway mode	28
3.2. CANopen Conformance Test Tool	29
A. FAQ - Frequently asked questions	30
B. Technical support	33
Abbreviations	34
Bibliography	35

List of Figures

1.1. Left view, AnaGate CAN USB	2
1.2. Right view, AnaGate CAN USB	3
2.1. HTTP interface, AnaGate CAN USB	17
2.2. HTTP interface, network settings	18
2.3. HTTP interface, CAN settings	19
2.4. HTTP interface, CAN settings	20
2.5. HTTP interface, Status	21
2.6. HTTP interface, Lua settings	23
2.7. AnaGate CAN USB, Example blinking output	25
2.8. HTTP interface, AnaGate CAN USB	26
2.9. HTTP interface, firmware update	26
3.1. AnaGate CAN USB in gateway mode	28

List of Tables

1.1. Technical data, AnaGate CAN USB	1
1.2. Pin layout, CAN plug	3
A.1. Using AnaGate hardware with firewall	31

List of Examples

3.1. Settings.ini	29
-------------------------	----

Introduction

This document describes the features and objectives of the CAN-USB-Gateway *AnaGate CAN USB*.

Chapter 1. Description

The *AnaGate CAN USB* connects a PC to a CAN bus via USB. It basically works as a CAN master with no own CAN identifier on the bus.

For this reason the *AnaGate CAN USB* provides a USB interface and a single electrically isolated CAN interface. On the PC side the *AnaGate CAN USB* identifies itself as a network card that allows TCP/IP based access to the connected CAN bus.

Controlling and configuration of an *AnaGate CAN USB* is made through TCP/IP. The application protocol itself is described in detail (see [TCP-2010]). Thus the access to the device can be programmed via native calls to the TCP/IP socket interface. This means that any communication partner with a LAN interface is able to communicate to the device. Accessing the device with the supplied application libraries for Windows and Linux is much comfortable. The libraries includes the entire range of device functions and can be used with conventional programming languages.

1.1. Features

- The *AnaGate CAN USB* can send and receive CAN messages via its CAN interface. This can be done using a PC that supports TCP sockets and USB.
- Variable CAN bus speed (10, 20, 50, 62.5, 100, 125, 250, 500, 800 or 1000 kbps).
- Software configurable bus termination for the CAN interface.
- The *AnaGate CAN USB* is powered directly via its USB port, no external supply is needed.
- Software interface implemented as virtual network adapter, easy access via TCP/IP.
- System is addressed using a proprietary network protocol.
- Static IP address configuration for the *AnaGate CAN USB*, the virtual PC network card is configured automatically via DHCP.
- Several simultaneous network connections (5x TCP) are supported on the CAN interface.

1.2. Specification

Technical aspect		Specification
Measurements	Desktop casing	120mm x 58mm x 32mm (WxLxH)
	Weight	approx. 125g
CAN bus	Baud rate	10, 20, 50, 62.5, 100, 125, 250, 500, 800 or 1000 kbps, software configuration
	CAN controller	1x Microchip MCP 2515
	CAN interface	1x ISO 11898-2, galvanic decoupled
	Interface	1x DB9 plug incl. CAN_H, CAN_L and GND
USB interface	Signaling rate	12 Mbps

Technical aspect		Specification
	TCP/IP	Static IP addresses, dynamic assignment (DHCP) to the PC
	Interface	USB connector type B
Voltage supply	Voltage	5V direct current via USB
	Power consumption	max. 500 mA
Ambient temperature	Storage	0 .. 85 °C
	In operation	0 .. 60 °C

Table 1.1. Technical data, AnaGate CAN USB



Note

Protect the *AnaGate CAN USB* from direct sunlight.

1.3. Scope of delivery

The *AnaGate CAN USB* is supplied with the following components:

- 1x AnaGate CAN USB
- 1x CD with manual, programming API for Windows/Linux and CANopen driver for CANFestival
- 1x USB 2.0 cable

1.4. Interfaces and plugs

1.4.1. AnaGate CAN USB - left view



Figure 1.1. Left view, AnaGate CAN USB

The left side of the *AnaGate CAN USB* features the following connectors and LEDs (from left to right):

USB Port The *AnaGate CAN USB* is connected to the PC via this USB port. A cable with a type A USB plug at its one end and a type B USB plug at the other end needs to be used.

Busy LED	This yellow LED lights up when the <i>AnaGate CAN USB</i> is processing incoming CAN messages.
Power LED	This green LED lights up when voltage is being supplied via the USB port.
Reset	The <i>AnaGate CAN USB</i> can be reset to the factory settings using this button (see Section 2.7, "Factory reset" for further details).

1.4.2. AnaGate CAN USB - right view



Figure 1.2. Right view, AnaGate CAN USB

The right side of the *AnaGate CAN USB* features the following connectors and LEDs (from left to right):

CAN port	9 pin D-sub connector to connect the CAN bus (CiA recommendation DS 102).
----------	---------------------------------------------------------------------------

The pin allocation of the plug can be inferred from the following table.

Pin	Description	
3	GND	
2	CAN_L	
1,4-6,8,9	not connected	
7	CAN_H	

Table 1.2. Pin layout, CAN plug

Activity LED	This green LED lights up on activity on the CAN line.
--------------	-------------------------------------------------------

Chapter 2. Configuration


2.1. Initial installation

First the *AnaGate CAN USB* must be connected to the PC via USB.


If the PC shows a notification that no device driver could be installed then please proceed as follows:

2.1.1. Microsoft Windows XP


1. If you use Microsoft Windows XP then the **Found New Hardware Wizard** opens when you first connect the *AnaGate CAN USB* to your PC.
2. If the **Found New Hardware Wizard** doesn't start automatically then you can also launch it manually:
 - a. Firstly, right-click the **My Computer** symbol, then click **Properties**.
 - b. In the **System Properties** window switch to the **Hardware** tab and click the **Device manager** button.
 - c. Right click the **RNDIS/Ethernet Gadget** entry that is marked with a yellow exclamation mark symbol and select Update Driver Software.
3. In the appearing wizard you first select **No, not this time** and then click **Next**.




4. Click **Install from a list or specific location (Advanced)**, and then click **Next**.



5. Click **Search for the best driver in these locations** and select the **Include this location in the search** checkbox. Insert the driver CD-ROM and select the driver file at `\drivers\AnaGateUSB\XP\linux.inf` on the CD-ROM by clicking the **Browse** button. Then click the **Next** button.



6. Confirm the Windows Logo warning with **Continue Anyway**.



7. The driver software installation finishes after a short waiting time.




2.1.2. Microsoft Windows 7 und Windows 8/8.1


1. If you use Microsoft Windows 7 and Windows 8, then open the Control Panel via the Start menu.
2. Switch the display mode in the upper right corner to small symbols.




3. Right click the **Device Manager** and launch it with administrator privileges. Enter your administrator password if prompted by the User Account Control.




4. Right click the entry **RNDIS/Ethernet Gadget** below **Other Devices** that is marked with a yellow exclamation mark symbol and select Update Driver Software.




5. In the appearing assistant you first select **Browse my computer for driver software**.




6. Then click **Let me pick from a list of device drivers on my computer**.




7. In the list of device types, choose **Network adapters** and click the **Next** button.




8. Firstly select **Microsoft Corporation** in the manufacturer list on the left and then **Remote NDIS Compatible Device** on the right.




9. Click **Next** and confirm the warning with **Yes**.




10. The driver software installation finishes after a short waiting time.






2.1.3. Microsoft Windows 10


1. If you use Microsoft Windows 10 you need to install a driver from the Microsoft Update Catalog. Launch the Microsoft Edge browser and navigate to <http://catalog.update.microsoft.com/v7/site/ScopedViewRedirect.aspx?updateid=37e35bd4-d788-4b83-9416-f78e439f90a2>. Decline the suggestion to use Internet Explorer and continue using Microsoft Edge.




- Download the **Acer Incorporated. - Other hardware - USB Ethernet/RNDIS Gadget** package. The update archive is named **20342321.cab**.




- Extract all files contained in the downloaded archive to a local folder. The archive should contain the files **rndis.cat** and **RNDIS.inf**.



- Navigate to the folder where you extracted the files. Right click on the file named **RNDIS.inf** and select Install. Confirm the following security prompts.




5. Right click the **Windows Start button** to open its context menu. Select the Device Manager entry.




6. Right click the entry **Serial USB device (COM3)** below **Ports (COM & LPT)** and select Update Driver Software.


If the computer has additional serial ports the entry you need to modify may have a different COM port number. You can check which number belongs to which device by removing and reconnecting the *AnaGate CAN USB*. The device manager automatically updates the shown list of connected devices.




7. In the appearing assistant you first select **Browse my computer for driver software**.




8. Then click **Let me pick from a list of device drivers on my computer.**



9. Select **USB Ethernet/RNDIS Gadget** from the list of compatible hardware models and click **Next**.



10. The driver software installation finishes after a short waiting time.



2.1.4. Factory settings

The *AnaGate CAN USB* is delivered with the following initial network settings:

IP address 192.168.2.1

Address type	static
Network mask	255.255.255.0
IP address PC	192.168.2.2

The device can now be configured using a standard browser (Internet Explorer, Firefox, etc.) by using `http://192.168.2.1`.




Figure 2.1. HTTP interface, AnaGate CAN USB

2.2. Network settings

On the page *IP Settings* the following settings can be changed.

Device IP address	The IP address of the <i>AnaGate CAN USB</i> is entered in dot format (e.g. 192.168.1.200).
PC IP address	This IP address in dot format (e.g. 192.168.1.201) is used by the PC. This IP address must be in the same subnet as the <i>AnaGate CAN USB</i> address.
USB Subnet mask	The subnet mask is entered in dot format (e.g. 255.255.255.0).




Figure 2.2. HTTP interface, network settings

The inputs will be taken over immediately after clicking the button **Save settings** and saved permanently on the *AnaGate CAN USB*. A restart of the device is not necessary for activation of the settings.



Note

After changing the IP address it may be necessary to clear the *ARP cache* of the PC to access the device.



Note

After changing the PC IP address the operating system may use the old address for another up to 15 minutes before it switches to the new value. If the change must be used immediately then temporarily disconnect the *AnaGate CAN USB* from the PC to enforce an update of the used address.

2.3. CAN settings

On the page *CAN Settings* the global settings for the CAN interface are displayed and can be changed individually.




Figure 2.3. HTTP interface, CAN settings

Baudrate	The baud rate can be selected easily via a list box containing all supported values.								
Termination	Use the check box to switch on/off the internal termination resistor.								
High Speed	Activates/deactivates the <i>Highspeed mode</i> . In this operating mode all incoming/outgoing CAN telegrams are not longer confirmed by the opposite LAN side to accelerate process throughput. Software-Filters are switched off too in this mode.								
Boot with operational mode	Initial operating mode of the CAN controller. Default value is offline .								
	<table> <tr> <td>offline</td><td>The CAN controller is not active on the CAN bus (offline).</td></tr> <tr> <td>normal</td><td>Normal operating mode. The default setting of CAN baud rate is used.</td></tr> <tr> <td>listen</td><td>In listen mode the CAN controller is passive. CAN messages are received, but no messages can be sent (no ACK, no error). The default setting of CAN baud rate is used.</td></tr> <tr> <td>loopback</td><td>In loopback mode every sent CAN message is mirrored back by the CAN controller (no ACK, no errors). The default setting of CAN baud rate is used.</td></tr> </table>	offline	The CAN controller is not active on the CAN bus (offline).	normal	Normal operating mode. The default setting of CAN baud rate is used.	listen	In listen mode the CAN controller is passive. CAN messages are received, but no messages can be sent (no ACK, no error). The default setting of CAN baud rate is used.	loopback	In loopback mode every sent CAN message is mirrored back by the CAN controller (no ACK, no errors). The default setting of CAN baud rate is used.
offline	The CAN controller is not active on the CAN bus (offline).								
normal	Normal operating mode. The default setting of CAN baud rate is used.								
listen	In listen mode the CAN controller is passive. CAN messages are received, but no messages can be sent (no ACK, no error). The default setting of CAN baud rate is used.								
loopback	In loopback mode every sent CAN message is mirrored back by the CAN controller (no ACK, no errors). The default setting of CAN baud rate is used.								

A more detailed description of the operating modes can be found in the data sheet of the CAN controller (Microchip MCP2515).

The inputs will be taken over immediately after clicking the button **Save settings** and saved permanently on the *AnaGate CAN USB*. A restart of the device is not necessary for activation of the settings.

2.4. Advanced settings

On the page *CAN Settings* the advanced settings of the unit are displayed and can be changed individually.




Figure 2.4. HTTP interface, CAN settings

Reception timer interval

This value specifies the frequency which is used to examine if new CAN telegrams are available in the internal driver buffer. The more frequently this examination is done, the shorter is the latency of the re-transmission of the CAN data via ethernet. On the other hand, its maximum message throughput is decreased.

The interval is defined in micro seconds, default value is 3000. To give control immediately to the firmware after a CAN telegram is received by the CAN driver, the value 0 has to be set.

The inputs will be taken over immediately after clicking the button **Save settings** and saved permanently on the *AnaGate CAN USB*. A restart of the device is not necessary for activation of the settings.

2.5. Device status

On the page *Status* the device dependand status information is shown.




Figure 2.5. HTTP interface, Status

TCP Receive	Number of via TCP/UDP received CAN messages (CAN firmware)
TCP Transmit	Number of via TCP/UDP transmitted CAN messages (CAN firmware)
CAN Receive	Number of received CAN messages (CAN bus, CAN driver)
CAN Transmit	Number of transmitted CAN messages (CAN bus, CAN driver)
CAN Discard	<ul style="list-style-type: none"> • Timeout sending CAN telegram (1s)

This indicates that no active partner is connected to the CAN bus (no ACK received). Also a wrong baud rate or missing termination can cause this error.

- A CAN telegram received from CAN bus is discarded because the receive buffer is full (600 entries)

This happens when the CAN firmware does not read telgrams fast enough out of the driver receive buffer. This may be the case even if CAN telegrams routed via TCP/UPD can not received fast enough by the connected ethernet client(PC,PLC) because of load problems (e.g. full receive TCP buffers).

- The firmware discards outgoing CAN telegrams because the send buffer is running full (1000 entries)

This happens when CAN telegrams are not sent fast enough successfully to CAN bus. This may be a resultant problem

of timeouts during transmission or of overloading the CAN bus concerning the current used baud rate.

CAN Receive Error	Register <i>Rx-Err-Count</i> of the CAN-Transceiver
CAN Transmit Error	Register <i>Tx-Err-Count</i> of the CAN-Transceiver
Network Error	TCP/UPD transmit error (CAN firmware)

After clicking the button **Clear** all saved diagnosis entries are deleted on the device. To reset the system counters the device must be switched off.

2.6. Functional extensions based on Lua

On an *AnaGate CAN USB* it is possible to execute self-created applications with an installed Lua script interpreter (see [Prog-2013] for a detailed description of all programming features).

On the page *Lua* Lua script files can be uploaded to the device and executed locally.




Figure 2.6. HTTP interface, Lua settings

Browse... Opens a file upload dialog to select a Lua script file.

Upload Uploads the selected script file to the device.

Clear Clears the current script file selection.

Boot script Script file executed on system startup. Via the button **Delete** the boot script can be deactivated. Only one boot script is allowed.

Running script Displays the currently executing script file. Via the button **Stop** the execution can be cancelled.

Available scripts Displays all scripts which are currently available on the device.

To start the execution of a script click on the button **Start**. Via button **Delete** a script can be deleted on the device and via **Boot** a script can be defined as boot script.

script output area In this text area the standard output (stdout) of the currently executing script is displayed. Via the button **Clear** this text area can be cleared.

error output area In this text area the standard error output (stderr) of the currently executing script is displayed. Via the button **Clear** this text area can be cleared.



Tip

The text areas for script and error output are not refreshed automatically. A manual page reload of the current page refreshes both text areas.

2.7. Factory reset

In order to restore the default factory settings, hold the *RESET* for approx. 10 seconds. If the device is reset successfully, the yellow LED blinks until the *RESET* is released.

The default factory settings are activated immediately without a restart of the device:

IP address	192.168.2.1
Address type	static
Network mask	255.255.255.0
IP address PC	192.168.2.2



Important

If the *RESET* push-button is pressed too briefly, the actual IP address and network mask is pulsed via the yellow LED (Morse code). A second push of the *RESET* terminates the pulsing, the device is not reset.



Note

The factory reset is not possible directly after power on until complete loading of the operating system and the firmware of the device. This initialization period is signalled via the yellow busy LED. On power on the LED is switched on and after initialization the LED is switched off.



Note

Maybe the *ARP cache* of the PC has to be deleted to find the device with the changed IP address.



Note

After changing the PC IP address the operating system may use the old address for another up to 15 minutes before it switches to the new value.

If the change must be used immediately then temporarily disconnect the *AnaGate CAN USB* from the PC to enforce an update of the used address.

2.7.1. Examining the network settings

It is possible to check the current network settings directly on the device.

After pressing shortly the *RESET* button the device starts to pulse out the current network settings via the yellow activity LED. Pressing again the buttons stops the pulsing immediately.

The IP address and subnet mask are pulsed out, one after the other. Following pulse codes are used:

- Digits 1, 2, 3, ..., 9: 1x, 2x, ...9x Flashing (200ms delay between each flash)
- Digit 0: 10x flashing (200ms delay between each flash)
- Dot: 1x very fast flash

Between two single digits a delay of 1 seconds is made, and between the IP address and subnet mask two fast flashes are pulsed out.

1 9 2 . 1 6 8 . 1 . 1|

■ ■■■■■■■■ ■■ □ ■ ■■■■■■ ■■■■■■■■ □ ■ □ ■ □□

Figure 2.7. AnaGate CAN USB, Example blinking output

2.8. Firmware update

The device firmware of the *AnaGate CAN USB* is updated via the integrated web server of the device.

On the home page of the web server the current firmware information is displayed.




Figure 2.8. HTTP interface, AnaGate CAN USB

Proceed please as follows, in order to install the firmware on the *AnaGate CAN USB*:

- Click *Firmware* on the left navigation bar to navigate to the Firmware-Upload page.




Figure 2.9. HTTP interface, firmware update

- Select the update package (file extension *.upd) via the **Browse** button.

- Clicking on the button **Upload** loads the update file to the device and starts the update process.
- During the update process several installation messages are displayed on the website. If the update is successfully finished, **Update done!** is displayed.

When the update is finished the browser navigates back to the home page. Check, if the new firmware version is displayed here.



Warning

If the firmware could not be flashed correctly on the device, the AnaGate may no longer be ready for operation.

Please visit our web site <http://www.anagate.de> for further information.

Chapter 3. Fields of application

If the *AnaGate CAN USB* is connected to the CAN bus, mind the following facts:

- **CAN_L**: This line has to be connected to the CAN_Low line of the CAN bus.
- **CAN_H**: This line has to be connected to the CAN_High line of the CAN bus.
- **GND**: This line can be connected optionally to GND of the other bus devices.

3.1. Gateway mode

In gateway mode the CAN messages are transferred transparently over TCP/IP between the CAN network and the PC in both directions. The *AnaGate CAN USB* uses no unique CAN ID when sending telegrams, this ID has to be set explicitly for each transmitted message.

All CAN messages received by the device are transmitted to all active application programs. It is possible to discard all incoming messages in general or to set individual software filters to reduce the message traffic to the applications.




Figure 3.1. AnaGate CAN USB in gateway mode

The *AnaGate CAN USB* can be accessed via the following interfaces:

- The software program CAN Monitor, which is included on the documentation CD, can be used to monitor a CAN bus or to create single CAN telegrams.
- Application programs which are using the included software API interface.
- Self-created batch files which are executed via the included Lua interpreter with integrated AnaGate software API.

3.2. CANopen Conformance Test Tool

The *CANopen Conformance Test Tool (CCT)* is a software tool, which is created and supported by the *CAN in Automation (CiA)*. It is used by the CiA to certificate CANopen devices. The Windows tool needs a hardware device to get access to the CAN bus and a manufacturer-specific application library called `COTI.dll`.

All CAN ethernet gateways and the CAN USB gateway offered by *Analytica GmbH* can be used by the *CANopen Conformance Test Tool* of the CiA.

To use the *AnaGate CAN USB* with the *CCT* the AnaGate-COTI extension must be copied to the installation path of the *CCT*. The COTI extension files can be found on the AnaGate CD in the path `Tools\COTI`. In addition, the configuration file `Settings.ini` must be customized. The configuration file must also be placed in the installation path of the *CCT*, it can be edited by a standard text editor like *Notepad*.

The following entries are contained in the file `Settings.ini`:

```
[Interface0]
IP=192.168.2.1
Port=0
```

Example 3.1. Settings.ini

IP IP-Address of the used *AnaGate CAN Gateway*.

Default address is `192.168.1.254`, this is the standard network address of all models with Ethernet interface.

For devices of model type *AnaGate CAN USB* the entry `IP=192.168.2.1` has to be used.

Port Used CAN Port of the *AnaGate CAN Gateway*.

For devices of model type *AnaGate CAN USB* the entry `Port=0` has to be used.

Appendix A. FAQ - Frequently asked questions

Here is a list of frequently asked questions.

A.1. Common questions

Q: No USB connection

A: Please check first the physical connection to the device. Basically the *AnaGate* has to be connected to a personal computer either directly or through a USB hub. To establish the connection a cable with a type A plug at one end and a type B plug at the other end needs to be used.



The physical interconnection is ok if the green power LED lights up while a USB cable is plugged in and is connected to a running PC. The green LED keeps being on until the connection breaks down.

If the power LED is always off then please check the wiring and the power supply via the PC.

Q: No network connection

A: If the power LED indicates a proper USB connection (see previous FAQ) but you still can't connect to the *AnaGate* then please try the following:

1. Check if the *AnaGate* can be reached via ping. To do so in Windows, open a command prompt and enter the command **ping a.b.c.d**", where a.b.c.d is the device IP address.
2. In case the *AnaGate* is unreachable via ping, reset the device to factory settings. Set up the PC network connection to the *AnaGate CAN USB* to obtain an IP address automatically. Check if the *AnaGate* can be reached via **ping 192.168.2.1**.

3. If the device can be reached via ping then the next step is to try if you can open a TCP connection to port 5001. Open a Windows command prompt and enter **telnet a.b.c.d 5001**, where a.b.c.d is the device IP address. If this command fails, check if a firewall runs on your PC.

Q: Using a firewall

A: When working with a firewall, the a TCP port has to be opened for communication with the AnaGate device:

Device	Port number
AnaGate I2C	5000
AnaGate CAN	5001
AnaGate CAN USB	5001
AnaGate CAN uno	5001
AnaGate CAN duo	5001, 5101
AnaGate CAN quattro	5001, 5101, 5201, 5301
AnaGate SPI	5002
AnaGate Renesas	5008
AnaGate Universal Programmer	5000, 5002, 5008
AnaGate UP 2.0	5000, 5002, 5008
AnaGate CAN X1	5001
AnaGate CAN X2	5001, 5101
AnaGate CAN X4	5001, 5101, 5201, 5301
AnaGate CAN X8	5001, 5101, 5201, 5301, 5401, 5501, 5601, 5701

Table A.1. Using AnaGate hardware with firewall

A.2. Questions concerning AnaGate CAN

Q: What is the value of the termination resistor when the termination option of the device is activated?

A: The termination resistor of the *AnaGate* is driven by a FET transistor. The resistor itself has 110 Ohm while the internal resistance of the FET is 10 Ohm if the FET is activated. So the resulting resistance is 120 Ohm, as required by the CAN bus.

Q: Does Analytica offer a CAN gateway which does not have a galvanically isolated CAN interface?

A: Any device that is actively connected to a CAN bus should be galvanically isolated. Especially when using USB-operated devices (like the *AnaGate USB*) it is essential to have a galvanically isolated device because the device is power supplied by the PC.

Q: How to directly interconnect two CAN ports!

- A:** If you want to interconnect two *AnaGate CAN* just via a direkt link CAN cable, you have to switch on the internal termination on both *AnaGate CAN* devices. A CAN bus network must have a termination on each side.



Note

it may work with lower baud rates without termination, but it is recommended to use a termination.

- Q:** Receiving a NAK when sending a CAN telegram.

- A:** If no CAN partner is connected to the *AnaGate CAN* (aka the CAN network), it is not possible to send CAN telegrams. The *AnaGate CAN* gets a NAK from the CAN controller. These NAK errors are sent to the AnaGate client via a data confirmation telegram.



Warning

If data confirmations are switched off no errors are sent to the client. The option *confirmations for data requests* can be set via the `CANSetGlobals` function. In High Speed Mode data confirmations are always disabled.

Appendix B. Technical support

The AnaGate hardware series, software tools and all existing programming interfaces are developed and supported by Analytica GmbH. Technical support can be requested as follows:

Internet

The AnaGate web site [<http://www.anagate.de/en/index.html>] of Analytica GmbH contains information and software downloads for AnaGate Library users:

- Product updates featuring bug fixes or new features are available here free of charge.

E-Mail

If you require technical assistance over the Internet please send an e-mail to

`<support@anagate.de>`

To help us provide you with the best possible support please keep the following information and details at hand when you contact our support team.

- Version number of the used programming tool or AnaGate library
- AnaGate hardware series model and firmware version
- Name and version of the operating system you are using

Abbreviations

I2C	Inter-Integrated Circuit
SCL	<u>S</u> erial <u>C</u> lock <u>L</u> ine
SDA	<u>S</u> erial <u>D</u> Ata <u>L</u> ine
SPI	<u>S</u> erial <u>P</u> eripheral <u>I</u> nterface
CLK	<u>C</u> lock <u>L</u>
MISO	<u>M</u> aster <u>I</u> n <u>S</u> lave <u>O</u> ut
SS	<u>S</u> lave <u>S</u> elect
MOSI	<u>M</u> aster <u>O</u> ut <u>S</u> lave <u>I</u> n
TRST	<u>T</u> est <u>R</u> eset
SRST	<u>S</u> lave <u>R</u> eset
JTAG	<u>J</u> oint <u>T</u> est <u>A</u> ction <u>G</u> roup
TDI	<u>T</u> est <u>D</u> ata <u>I</u> nput
TDO	<u>T</u> est <u>D</u> ata <u>O</u> utput
TMS	<u>T</u> est <u>M</u> ode <u>S</u> elect Input
TCK	<u>T</u> est <u>C</u> lock
DHCP	<u>D</u> ynamic <u>H</u> ost <u>C</u> onfiguration <u>P</u> rotocol

Bibliography

Books

[LuaRef2006-EN] Roberto Ierusalimschy, Luiz Henrique Figueiredo, and Waldemar Celes. Copyright © 2006 R. Ierusalimschy, L. H. de Figueiredo, W. Celes. ISBN 85-903798-3-3. Lua.org. *Lua 5.1 Reference Manual*.

[LuaProg2006-EN] Roberto Ierusalimschy. Copyright © 2006 Roberto Ierusalimschy, Rio de Janeiro. ISBN 85-903798-2-5. Lua.org. *Programming in Lua (second edition)*.

[LuaProg2013-EN] Roberto Ierusalimschy. Copyright © 2013 Roberto Ierusalimschy, Rio de Janeiro. ISBN 85-903798-5-X. Lua.org. *Programming in Lua, Third Edition*.

Other publications

[NXP-I2C] NXP Semiconductors. Copyright © 2007 NXP Semiconductors. *UM10204*. I2C-bus specification and user manual. Rev. 03. 19.06.2007.

[TCP-2010] Analytica GmbH. Copyright © 2010 Analytica GmbH. *Manual TCP-IP communication*. Version 1.2.6. 15.05.2008.

[Prog-2013] Analytica GmbH. Copyright © 2013 Analytica GmbH. *AnaGate API 2*. Programmer's Manual. Version 2.0. 15.05.2013.

[CiA-DS301] Copyright © 2002 CAN in Automation (CiA) e. V.. CAN in Automation (CiA) e.V.. 13.02.2002. *Cia 301, CANopen Application Layer and Communication Profile*.